

HEP-3 System Procedure

- 1. Soak the gel, membrane and blotting filter paper in transfer buffer**
- 2. Arrange a sandwich consisting of presoaked blotting filter paper, gel and membrane**
- 3. Place the sandwich on the base, cover with the lid and connect to your power supply**

© 2012 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

>> For more information, visit: www.thermoscientific.com/owlsci